

9200/9205/9210/9215 User Guide



Compatible Equipment:

9040	Internal Sounder
660	Speech Communicator
9220	Remote Keypad for 9210 and 9215
8506	Eurobell

User Commands

Set/Unset System	User code
Part Set	User code + OMIT2 + ENTER
Test Bells	BELL TEST + ENTER + User code
Walk Test	WALK TEST + ENTER User code User code to end test
Change User code	6 + ENTER current user code new user code + ENTER